

Maintenance Instructions



1

DAILY:
Remove lid and empty strainer basket



2

DAILY:
Clean residue off channel



3

DAILY:
Empty collection container



4

DAILY:
Remove lid and clean wiper blades

5 1-3 TIMES WEEKLY: Flush through with clean hot water from the sink tap for 5 minutes to clear sediments and to reduce odours.

6 EVERY 3 MONTHS: Tank pump out required by service partner

See owner's manual for more detailed information



BS EN ISO 9001 : 2008

**Grease
Guardian[®]**
Frontline Engineering

FOR SERVICE CALL +44(0)28 302 66616

www.greaseguardian.com

www.greaseguardianusa.com